SUBMERSIBLE PUMP

designed for fountains

Model No. PT-707

■ MAINTENANCE

To clean the pump, remove the front plate and the impeller. Use a small brush or stream of water to remove any debris.

CAUTION : The pump shaft can not be removed. **If THE PUMP FAILS TO OPERATE, CHECK THE FOLLOWING:**

- Check the circuit breaker and another outlet to ensure the pump is getting electrical power. NOTE: Always disconnect from electrical outlet before handling the pump.
- Check the pump discharge and tubing for kinds and obstructions Algae build up can be flushed out with a garden hose.
- Remove the pump inlet to access the impeller area. Turn the rotor to ensure it is not broken or jammed.
- Monthly maintenance will add to your pump's life. NOTE: Ensure that the electrical cord loops below the electrical outlet to form a 'Drip Loop' This will prevent water from running down the cord into the electrical outlet.